

ADM51 Emulator

- 1 **Register at www.signum.com/myaccount.htm** to qualify for tech support, S/W updates, manufacturer warranty, and special offers.
- 2 **Insert CD** Insert the Signum **USP-ADM51** CD into the drive. The installation documentation is available from the initial Master Setup screen of the CD. After installation, the complete product documentation will be accessible through the Windows Start menu.
- 3 **Install USB driver** Plug the emulator into the USB port. If prompted by the *Found New Hardware* wizard, point to the **SigUSB.inf** file in the root of the CD. See *USB 2.0 Driver for JTAGjet and ADM51: Installation Instructions* (jtagjet_usb_install.pdf) for details if needed.
- 4 **Install software** In the Master Setup dialog box, select **ADM51 Emulator** and follow instructions. See *Chameleon WEMU51 Debugger for ADM51: Installation Instructions* (jtagjet_usb_install.pdf) for details.
- 5 **Configure target** Connect the ADM51 to the target board, power the board, start your debugger and configure the target. See *Chameleon WEMU51 Debugger for ADM51: Installation Instructions* (jtagjet_usb_install.pdf) for more information on how to configure target boards.

Remember to register at www.signum.com/myaccount.htm ■